

Exercise 4-4

1. Continue from Exercise 4-3 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX4-4.
3. Use the **ARC** command and the **Continue** option as described in the textbook to draw an arc connected to a previously drawn line, as shown in Figure 4-10A. Use the technique to draw a slot of your own design. Experiment with holding down [Ctrl] while the **ARC** command is active to reverse the direction of the arc.
4. Use the **ARC** command and the **Continue** option to draw the arcs shown in Figure 4-10B.
5. Resave and close the file.
6. Continue to practice using the **ARC** command by completing act04-04.dwg available on the companion website.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.