

## Exercise 24-5

1. Continue from Exercise 24-4 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the file as EX24-5a.
3. Open **DesignCenter**.
4. In the **Tree View** pane, navigate to the AutoCAD 2018\Sample\en-us\DesignCenter folder.
5. Insert two blocks from the Fasteners - US.dwg file.
6. Insert two blocks from the Basic Electronics.dwg file.
7. Resave and close the file.
8. Start a new drawing from scratch or use a template of your choice. Save the file as EX24-5b.
9. Open the **Tool Palettes** palette.
10. Insert two blocks from the **Civil** tab. Adjust the scale of each block during insertion.
11. Resave and close the file.
12. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.