

Exercise 29-5

1. Continue from Exercise 29-4 or start AutoCAD.
2. Open the EX29-4 file you saved during Exercise 29-4.
3. Save a copy of EX29-4 as EX29-5. The EX29-5 file should be active.
4. Make the **A-Size** layout current.
5. Activate the floating viewport.
6. Scale the floating viewport to $3/4" = 1'-0"$.
7. Use the **PAN** command to center the view in the upper portion of the viewport.
8. Reactivate paper space.
9. Lock the floating viewport.
10. Activate the floating viewport.
11. Try to zoom in and out and pan. Notice that when you lock a viewport, AutoCAD does not allow you to change the display showing through the viewport. The commands apply to the entire paper space drawing instead of the viewport.
12. Change the title in the title block from EXERCISE 29-4 to EXERCISE 29-5.
13. Resave and close the file.
14. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.