

## Exercise 20-13

1. Continue from Exercise 20-12 or start AutoCAD.
2. Open an existing drawing that contains several leaders created using the **MLEADER** command.
3. Save a copy of the drawing as EX20-13. The EX20-13 file should be active.
4. Experiment with aligning the leaders using the **MLEADERALIGN** command.
5. Resave and close the file.
6. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.