

Exercise 2-4

1. Open drawing EX2-3.
2. Use the **INTERFERE** command to check the interference between the box and the four cylinders.
3. Make the settings necessary in the **Interference Checking** dialog box so the interference solids are not deleted and then close the dialog box.
4. Observe the results. How does this command differ from the **INTERSECT** command?
5. Save the drawing as EX2-4.

To continue practicing with interference solids, complete act02-04.dwg available on the companion website.