AutoCAD and Its Applications ADVANCED

Exercise 3-3

- 1. Open the drawing Pergola_bridge.dwg provided on the companion website.
- 2. Display the view cube if it is not already displayed. Also, turn on the UCS icon if it is not already on.
- 3. Set the Conceptual visual style current.
- 4. Open the **View Cube Settings** dialog box. All work in this exercise will use this dialog box.
- 5. Change the location of the view cube. Exit the dialog box to see the new position.
- 6. Change the size and opacity of the view cube. Exit the dialog box each time to see the results.
- 7. Change the opacity of the view cube to zero. Exit the dialog box and locate the view cube.
- 8. One at a time, turn off the options in the **When clicking on the View Cube** area of the **View Cube Settings** dialog box. Test each one to see how it affects the appearance and function of the view cube and the model display.
- 9. Close the drawing without saving.