

Exercise 8-4

1. Open the drawing created in the last exercise (EX8-3).
2. Use the **MIRROR3D** command to mirror the wedge to the position shown in the illustration below.
3. Save the drawing as EX8-4.

