

Exercise 10-5

In this exercise, you will create an offset surface.

1. Open the drawing EX10_05.dwg available on the companion website.
2. Make sure the **SURFACEMODELINGMODE** system variable is set to 0 (the default setting).
3. Make sure the **SURFACEASSOCIATIVITY** system variable is set to 1 (the default setting).
4. Using the **SURFOFFSET** command, create an offset to the inside of the hair dryer using the **Solid** option. See the illustration below. Set the offset distance to .0625.
5. Save the drawing as EX10-5.

