

Exercise 20-1

1. Open the drawing Bracket.dwg available on the companion website.
2. Enter the **NAVSMOTION** command to display the **ShowMotion** toolbar.
3. Move the cursor over the toolbar and identify each button.
4. Pick the **New Shot...** button to display the **New View/Shot Properties** dialog box. Then, select the **View Properties** tab.
5. Pick the **Define window** button and draw a rectangular window that is close to the boundary of the model.
6. Select Realistic from the **Visual style:** drop-down list in the **View Properties** tab.
7. In the **View Properties** tab, select Solid in the drop-down list in the **Background** area. In the **Background** dialog box, pick the lower color swatch and set the color to ACI 151 (light blue) in the **Select Color** dialog box that is displayed. Close the **Select Color** and **Background** dialog boxes.
8. In the **New View/Shot Properties** dialog box, enter Close-up in the **View name:** text box. Also, select Still in the **View type:** drop-down list.
9. In the **Shot Properties** tab, set the transition and motion durations for 2 seconds each. Preview the shot. Then, close the **New View/Shot Properties** dialog box.
10. Save the drawing as EX20-1.