Exercise 24-6

1. Continue from Exercise 24-5 or start AutoCAD.
2. Open the EX24-2 file you saved during Exercise 24-2.
3. Save a copy of EX24-2 as EX24-6. The EX24-6 file should be active.
4. Use the **BEDIT** command to modify the original PLATE-1 block by changing the ∅1.0 and ∅1.5 circles to ∅1.24 each.
5. Save the changes to the block.
6. Resave and close the file.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.

Copyright Goodheart-Willcox Co., Inc.
May not be reproduced or posted to a publicly accessible website.