

## Exercise 11-4

1. Continue from Exercise 11-3 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX11-4.
3. Draw objects similar to the “Before Chamfer” objects shown in Figure 11-8, and then use the **Trim** and **No trim** options as needed to create objects similar to the “After” objects.
4. Draw three linked (consecutive and intersecting) nonparallel polyline segments with endpoints that would intersect if extended. Use the **CHAMFER** command and appropriate distances greater than 0 to connect the polylines and form a single polyline object with a chamfered corner.
5. Resave and close the file.
6. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.