

## Exercise 14-4

1. Continue from Exercise 14-3 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX14-4.
3. Draw a polyline with at least five vertices. Draw a second polyline with the same number of vertices. Make each polyline smooth using the **Fit** option of the **PEDIT** command.
4. Return one polyline to its original form using the **Decurve** option of the **PEDIT** command.
5. Practice with the **Undo** option by first drawing a series of polyline segments. After using the **PEDIT** command to make several changes, use the **Undo** option to return to the original polyline.
6. Resave and close the file.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.