

## Exercise 11-10

1. Continue from Exercise 11-9 or start AutoCAD.
2. Start a new drawing from scratch or use a decimal-unit template of your choice. Save the drawing as EX11-10.
3. Draw a polyline of your own design. Include several different segment widths. Explode the polyline and observe what happens.
4. Erase one of the individual segments.
5. Create a multiline text object with at least two lines of text. Explode the multiline text object and observe what happens. Double-click on a line of text to verify that the text is now a single-line text object.
6. Resave and close the file.
7. Keep AutoCAD open for the chapter review and problems, or exit AutoCAD if necessary.