

## Exercise 20-11

1. Continue from Exercise 20-10 or start AutoCAD.
2. Start a new drawing from scratch or use a decimal-unit template of your choice. Save the drawing as EX20-11.
3. Set up appropriate layers, including a layer for dimensions.
4. Create the objects, including the center marks and centerlines, shown in the Process column in Figure 20-20. Use appropriate center mark and centerline settings.
5. Use grip editing to change the center marks and centerlines as shown in the Result column in Figure 20-20.
6. Resave and close the file.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.