

Exercise 20-14

1. Continue from Exercise 20-13 or start AutoCAD.
2. Start a new drawing from scratch or use a decimal-unit template of your choice. Save the drawing as EX20-14.
3. Set up appropriate layers, including a layer for dimensions.
4. Draw an assembly view similar to the view shown on the right side in Figure 20-24.
5. Create a multileader style that uses the **Block** content type and **Circle** source block.
6. Use the **MLEADER** command to draw three separate leaders: one tagged 1, another tagged 2, and a third tagged 3. Each leader should touch the hex head screw and point to its center.
7. Group the balloons to create the single leader line shown in Figure 20-24.
8. Resave and close the file.
9. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.