

## Exercise 26-2

1. Continue from Exercise 26-1 or start AutoCAD.
2. Open the EX26-1 file you saved during Exercise 26-1.
3. Save a copy of EX26-1 as EX26-2. The EX26-2 file should be active.
4. Open the DOOR block in the **Block Editor**.
5. Assign a move action to the DOOR TAG parameter. Select the circle and tag text as the objects to which the action applies.
6. Enter the **Test Block Window**.
7. Select the point parameter grip in the center of the circle and move it to a new location.
8. Close the **Test Block Window** and make changes to the block if the tag did not move as expected.
9. Retest the block if you made changes.
10. Save the block and exit the **Block Editor**.
11. Insert the DOOR block into the current drawing.
12. Select the block to display grips. Select the point parameter grip in the center of the circle and move it to a new location.
13. Resave and close the file.
14. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.