

## Exercise 11-2

In this exercise, you will subobject edit fillets and a chamfer on a 3D solid part.

1. Open the drawing Edit\_Fillet\_Chamfer.dwg available on the companion website.
2. Press and hold the [Ctrl] key and pick each fillet to select all fillets.
3. Right-click and open the **Properties** palette.
4. Change the radius of all fillets to .300.
5. Deselect the fillets and leave the **Properties** palette open.
6. Press and hold the [Ctrl] key and pick the chamfer.
7. In the **Properties** palette, set both distances to .500.
8. The new part should look like the illustration below.
9. Save the drawing as EX11-2.

