

Exercise 12-6

1. Open drawing EX12-5.
2. Use the **Face>Color** option of the **SOLIDEDIT** command to change the color of the tapered box and the interior of the hole.
3. Copy the bottom face of the box down and away from the object.
4. Extrude the copied face to a thickness of your choice.
5. Save the drawing as EX12-6.