AutoCAD and Its Applications ADVANCED

Exercise 18-1

- 1. Start a new drawing.
- 2. Draw a planar surface and place various solid primitives on top of it.
- 3. Turn on sunlight and turn the default lighting off. Access the sunlight properties.
- 4. Display a pictorial view, if one is not already displayed.
- 5. Render the scene.
- 6. Set the geographic location to your hometown, or a large city near it, and render the scene again.
- 7. Change the date and time settings and render the scene again.
- 8. One by one, select each image in the **Render** window and note the differences between them.
- 9. Save the drawing as EX18-1.

To continue practicing rendering with sunlight, complete act18-01.dwg available on the companion website.