

Exercise 31-5

1. Continue from Exercise 31-4 or start AutoCAD.
2. Open the EX31-1 file you saved during Exercise 31-1.
3. Save a copy of EX31-1 as EX31-5. The EX31-5 file should be active.
4. Use the **XBIND** command to bind the S-ANNO and S-DETL layers, the ARCH dimension style, and the ARCH text style.
5. Detach the Detail 5 xref.
6. Check for the new bound definitions in the appropriate dialog boxes.
7. Resave and close the file.
8. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.