

## Exercise 10-2

1. Continue from Exercise 10-1 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX10-2.
3. Use the **TEXT** command and control codes to type the following:  
45°  
1.375±.005  
Ø3.875  
79%  
UNDERSCORING TEXT
4. Resave and close the file.
5. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.