

Exercise 18-6

1. Continue from Exercise 18-5 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX18-6.
3. Set up the appropriate layers, including a layer for annotations.
4. Draw objects similar to those in Figure 18-26. Create the multileader styles needed to add the leaders shown. Use the **MLEADER** command to add the leaders.
5. Use the **MLEADER** command to do the following. Create multileader styles as needed.
 - Draw a leader using each of the three placement options.
 - Create a multileader style that uses the **Block** multileader type. Create leaders using the new style.
 - Create a multileader style that uses the **None** multileader type. Create leaders using the new style.
 - Experiment by adjusting multileader style settings and observe the changes made to existing leaders.
6. Resave and close the file.
7. To continue practicing using the **MLEADER** command, complete the activity in act18-06.dwg available on the companion website.
8. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.