## **AutoCAD and Its Applications BASICS**

## **Exercise 29-8**

- 1. Continue from Exercise 29-7 or start AutoCAD.
- 2. Open the EX29-7 file you saved during Exercise 29-7.
- 3. Save a copy of EX29-7 as EX29-8. The EX29-8 file should be active.
- 4. Make **My Layout** current.
- 5. Activate floating viewports as needed and use the **Layer Properties Manager** to create the following layer property overrides:
  - A. Override the color applied to the circle to green.
  - B. Override the linetype applied to the ellipse to Continuous.
  - C. Override the color applied to the hexagon to 114, and override the lineweight to 1.00 mm. Pick the **Show/Hide Lineweight** button on the status bar, if it is not selected, to display lineweights.
- 6. Reactivate paper space.
- 7. Pick the **Model** tab to enter model space. Notice how all objects appear using the global layer properties.
- 8. Re-enter paper space.
- 9. Resave and close the file.
- 10. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.