

## Exercise 32-4

1. Continue from Exercise 32-3 or start AutoCAD.
2. Save a copy of the S-02.dwg file from the companion website to the Structural folder you created during Exercise 32-3. Open the file and explore the contents. Notice that the file includes a single layout with the same name as the file. Close the file without saving.
3. Open the Cappuccino Express sheet set you created in Exercise 32-2.
4. Double-click on the 2 - G-01 sheet to open the file and display the layout.
5. Right-click on the Structural subset and select **Import Layout as Sheet....**
6. Add the **S-02** layout from the S-02.dwg file you saved in Step 2 to the Structural subset.
7. Double-click on the S-02 sheet in the **Sheet Set Manager** to open the file and display the layout.
8. Right-click on the Cappuccino Express sheet set in the **Sheet Set Manager** and select **New Sheet....**
9. Give the sheet a number of 3 and a title of S-01. Remove the 3 and space from the default file name. Check **Open in drawing editor** and then pick the **OK** button to create and open the sheet and display the layout.
10. Delete the floating viewport from the **S-01** layout.
11. Save and close all open drawings.
12. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.