

Exercise 33-2

1. Continue from Exercise 33-1 or start AutoCAD.
2. Open the Cappuccino Express sheet set you created in Exercise 32-2.
3. Activate the **Sheet List** tab of the **Sheet Set Manager** and double-click on the 1 - G-01 sheet to open the file and display the layout. Ensure that you are in paper space and that no floating viewport is active.
4. Apply a **ZOOM All** operation.
5. Access the **NEWVIEW** command and create a new layout view named Elevations. Add the view to the Elevations category and use the **Current display** option.
6. Return to the **Sheet List** tab of the **Sheet Set Manager** and double-click on the 2 - A-01 sheet to open the file and display the layout. Ensure that you are in paper space and that no floating viewport is active.
7. Apply a **ZOOM All** operation.
8. Access the **NEWVIEW** command and create a new layout view named Floor Plan. Add the view to the Floor Plan category and use the **Current display** option.
9. Return to the **Sheet List** tab of the **Sheet Set Manager**. Right-click on the 4 - S-02 sheet and pick **Open** to open the file and display the layout. Ensure that you are in paper space and that no floating viewport is active.
10. Apply a **ZOOM All** operation.
11. Access the **VIEW** command and create a new layout view named Section. Add the view to the Structural category and use the **Current display** option.
12. Right-click on the Section sheet view and select **Rename & Renumber...** to display the **Rename & Renumber View** dialog box. Type A in the **Number:** text box, and pick the **OK** button to exit.
13. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.