

## Exercise 16-2

1. Continue from Exercise 16-1 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice.
3. Open the **Dimension Style Manager** dialog box, pick the **Modify...** button, and access the **Text** tab.
4. Pick each of the **Horizontal** justification options and watch how the preview image changes with each selection.
5. Pick each of the **Vertical** justification options and watch how the preview image changes with each selection.
6. Choose each **View Direction** option and watch how the preview image changes with each selection.
7. Access the **Fit** tab. Select the various options and notice how the preview image changes.
8. Close the **Dimension Style Manager** without saving changes.
9. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.