

Architectural Drafting Using AutoCAD

Command Aliases



Command/Tool	Alias	Command/Tool	Alias
3DALIGN	3AL	BACTION	AC
3DARRAY	3A	BCLOSE	BC
3DFACE	3F	BEDIT	BE
3DMOVE	3M	BLOCK	B
3DORBIT	3DO, ORBIT	-BLOCK	-B
3DPOLY	3P	BOUNDARY	BO
3DROTATE	3R	-BOUNDARY	-BO
3DWALK	3DW	BPARAMETER	PARAM
ACTRECORD	ARR	BREAK	BR
ACTSTOP	ARS	BSAVE	BS
-ACTSTOP	-ARS	BVSTATE	BVS
ACTUSERINPUT	ARU	CAMERA	CAM
ACTUSERMESSAGE	ARM	CHAMFER	CHA
-ACTUSERMESSAGE	-ARM	CHANGE	-CH
ADCENTER	ADC, DC, DCENTER	CHECKSTANDARDS	CHK
ALIGN	AL	CIRCLE	C
ALLPLAY	APLAY	COLOR	COL, COLOUR
APPLOAD	AP	COMMANDLINE	CLI
ARC	A	COPY	CO, CP
AREA	AA	CTABLESTYLE	CT
ARRAY	AR	CYLINDER	CYL
-ARRAY	-AR	DATAEXTRACTION	DX
ATTDEF	ATT	DATALINK	DL
-ATTDEF	-ATT	DATALINKUPDATE	DLU
ATTEDIT	ATE	DBCONNECT	DBC
-ATTEDIT	-ATE, ATTE	DDEDIT	ED
ATTIPEDIT	ATI	DDGRIPS	GR
		DDVPOINT	VP

(Continued)

Command/Tool	Alias	Command/Tool	Alias
DIMALIGNED	DAL	FILLET	F
DIMANGULAR	DAN	FILTER	FI
DIMARC	DAR	FLATSHOT	FSHOT
DIMBASELINE	DBA	GEOGRAPHICLOCATION	GEO, NORTH, NORTHDIR
DIMCENTER	DCE	GRADIENT	GD
DIMCONTINUE	DCO	GROUP	G
DIMDIAMETER	DDI	-GROUP	-G
DIMDISASSOCIATE	DDA	HATCH	BH, H
DIMEDIT	DED	-HATCH	-H
DIMJOGGED	JOG, DJO	HATCHEDIT	HE
DIMJOGLINE	DJL	HIDE	HI
DIMLINEAR	DLI	HIDEPALETTES	POFF
DIMORDINATE	DOR	IMAGE	IM
DIMOVERRIDE	DOV	-IMAGE	-IM
DIMRADIUS	DRA	IMAGEADJUST	IAD
DIMREASSOCIATE	DRE	IMAGEATTACH	IAT
DIMSTYLE	D, DST	IMAGECLIP	ICL
DIST	DI	IMPORT	IMP
DIVIDE	DIV	INSERT	I
DONUT	DO	-INSERT	-I
DRAWINGRECOVERY	DRM	INSERTOBJ	IO
DRAWORDER	DR	INTERFERE	INF
DSETTINGS	DS, SE	INTERSECT	IN
DVIEW	DV	JOIN	J
EDITSHOT	ESHOT	LAYER	LA
ELLIPSE	EL	-LAYER	-LA
ERASE	E	LAYERSTATE	LAS, LMAN
EXPLODE	X	-LAYOUT	LO
EXPORT	EXP	LENGTHEN	LEN
-EXPORTTOAUTOCAD	AECTOACAD	LINE	L
EXTEND	EX	LINETYPE	LT, LTYPE
EXTERNALREFERENCES	ER	-LINETYPE	-LT, -LTYPE
EXTRUDE	EXT		

(Continued)

Command/Tool	Alias	Command/Tool	Alias
LIST	LI, LS	PASTESPEC	PA
LTSCALE	LTS	PEDIT	PE
LWEIGHT	LW, LINEWEIGHT	PLINE	PL
MARKUP	MSM	PLOT	PRINT
MATCHPROP	MA	POINT	PO
MATERIALS	MAT	POINTLIGHT	FREEPOINT
MEASURE	ME	POLYGON	POL
MIRROR	MI	POLYSOLID	PSOLID
MIRROR3D	3DMIRROR	PREVIEW	PRE
MLEADER	MLD	PROPERTIES	CH, MO, PR, PROPS
MLEADERALIGN	MLA	PROPERTIESCLOSE	PRCLOSE
MLEADERCOLLECT	MLC	PSPACE	PS
MLEADEREDIT	MLE	PUBLISHTOWEB	PTW
MLEADERSTYLE	MLS	PURGE	PU
MLINE	ML	-PURGE	-PU
MOVE	M	PYRAMID	PYR
MSPACE	MS	QLEADER	LE
MTEXT	MT, T	QUICKCALC	QC
-MTEXT	-T	QUICKCUI	QCUI
MVIEW	MV	QUIT	EXIT
NAVSMOTION	MOTION	QVDRAWING	QVD
NAVSMOTIONCLOSE	MOTIONCLS	QVDRAWINGCLOSE	QVDC
NAVSWHEEL	WHEEL	QVLAYOUT	QVL
NAVVCUBE	CUBE	QVLAYOUTCLOSE	QVLC
NEWSHOT	NSHOT	RECTANG	REC
NEWVIEW	NVIEW	REDRAW	R
OFFSET	O	REDRAWALL	RA
OPTIONS	OP	REGEN	RE
OSNAP	OS	REGENALL	REA
-OSNAP	-OS	REGION	REG
PAN	P	RENAME	REN
-PAN	-P	-RENAME	-REN
-PARTIALOPEN	PARTIALOPEN		

(Continued)

Command/Tool	Alias	Command/Tool	Alias
RENDER	RR	THICKNESS	TH
RENDERCROP	RC	TILEMODE	TI
RENDERPRESETS	RP	TOLERANCE	TOL
RENDERWIN	RW	TOOLBAR	TO
REVOLVE	REV	TOOLPALETTES	TP
ROTATE	RO	TORUS	TOR
RPREF	RPR	TRIM	TR
SCALE	SC	UCSMAN	UC
SCRIPT	SCR	UNION	UNI
SECTION	SEC	UNITS	UN
SECTIONPLANE	SPLANE	-UNITS	-UN
SEQUENCEPLAY	SPLAY	VIEW	V
SETVAR	SET	-VIEW	-V
SHADEMODE	SHA	VIEWGO	VGO
SHEETSET	SSM	VIEWPLAY	VPLAY
SHOWPALETTES	PON	VISUALSTYLES	VSM
SLICE	SL	-VISUALSTYLES	-VSM
SNAP	SN	VPOINT	-VP
SOLID	SO	VSCURRENT	VS
SPELL	SP	WBLOCK	W
SPLINE	SPL	-WBLOCK	-W
SPLINEDIT	SPE	WEDGE	WE
STANDARDS	STA	XATTACH	XA
STRETCH	S	XBIND	XB
STYLE	ST	-XBIND	-XB
SUBTRACT	SU	XCLIP	XC
TABLE	TB	XLINE	XL
TABLESTYLE	TS	XREF	XR
TABLET	TA	-XREF	-XR
TEXT	DT	ZOOM	Z