

## Exercise 16-3

1. Continue from Exercise 16-2 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice.
3. Open the **Dimension Style Manager** dialog box, pick the **Modify** button, and access the **Primary Units** tab.
4. Adjust each option in the **Linear dimensions** and **Angular dimensions** areas and watch how the preview image changes with each selection.
5. Access the **Alternate Units** tab and pick the **Display alternate units** check box. Select the various options and watch how the preview image changes.
6. Close the **Dimension Style Manager** without saving changes.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.