

Exercise 20-2

1. Open the drawing Pergola_bridge.dwg available on the companion website.
2. Enter the **NAVSMOTION** command.
3. Open the **New View/Shot Properties** dialog box.
4. Set the view type to Recorded Walk and enter the view name Walk01.
5. Begin recording the shot by walking to the left, then straight toward the bridge and stop recording. The recording should be approximately 10 seconds in length.
6. Preview the shot. Re-record it if there are jerky or extremely fast movements.
7. Once the preview is acceptable, pick the **OK** button to save the shot.
8. Create another walk shot. Enter the name Walk02.
9. Begin recording the walk by moving to the left or right to bring the model toward the center of the screen. Then, move straight toward the pergola. Press the [Shift] key and lower your point of view to move the model higher on the screen. Release the [Shift] key and continue moving closer to the pergola. Stop recording.
10. Preview the shot. It should be no longer than 25 seconds. When the shot is acceptable, pick the **OK** button to save the shot.
11. Save the drawing as EX20-2.