

Exercise 20-10

1. Continue from Exercise 20-9 or start AutoCAD.
2. Start a new drawing from scratch or use a metric-unit template of your choice.
Save the drawing as EX20-10.
3. Set up appropriate layers, including a layer for dimensions.
4. Draw and dimension an object similar to the object shown in Figure 20-16. Use an appropriate dimension style.
5. Use the **DIMBREAK** command to add the breaks shown in Figure 20-17.
6. Resave and close the file.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.