AutoCAD and Its Applications BASICS


Reference Material

Drafting Symbols

Symbols provide a "common language" for drafters all over the world. However, symbols are meaningful only if they are drawn according to relevant standards or conventions. This document describes and illustrates common dimensioning, GD&T, architectural, piping, and electronic symbols.


Recommended ASME Dimensioning Symbols

The size of dimensioning symbols is consistent with text height. In the following illustration, H = text height.




Geometric Dimensioning and Tolerancing Symbols

You can create a library of GD&T symbols, use AutoCAD GD&T tools, or use an AutoCAD GD&T font to insert symbols as text. The following tables show examples of GD&T symbols. For complete coverage of GD&T, refer to Geometric Dimensioning and Tolerancing by David A. Madsen and David P. Madsen, published by Goodheart-Willcox.




Datum Feature Symbol




Datum Target Symbol

Movable Datum Target Symbol


Datum Target Symbols



Geometric Characteristic Symbols




Material Condition and Material Boundary Symbols




Feature Control Frame Symbol



H = Letter heightBasic Dimension Symbol





 $\begin{tabular}{ll} \textbf{Tolerance} & \textbf{Feature} \\ \\ \textbf{H} = \textbf{Letter height} \\ \end{tabular}$


Additional GD&T Symbols

To draw GD&T symbols as text, create a style using the gdt.shx font. Then use the lowercase alphabet to type the symbols. The following table shows the symbol produced by each lowercase letter.

| Lowercase Letter | Symbol Produced | | |
|------------------|-------------------|--|--|
| а | _ | | |
| b | | | |
| С | | | |
| d | | | |
| е | 0 | | |
| f | // | | |
| g | A | | |
| h | A | | |
| i | = | | |
| j | + | | |
| k | | | |
| I | | | |
| m | M | | |
| n | Ø | | |
| 0 | | | |
| р | P | | |
| q | ¢. | | |
| r | 0 | | |
| S | S | | |
| t | 2A | | |
| u | | | |
| V | | | |
| W | | | |
| Х | $\overline{\psi}$ | | |
| У | | | |
| Z | | | |

Architectural Symbols

The following table shows basic examples of architectural drafting symbols.



Piping Symbols

The following table shows basic examples of piping drafting symbols.

| Single-Line Piping Symbols | | | | | | | |
|----------------------------|-----------|----------|------------------|------------|----------|--------------|--|
| | Screwed | | | Buttwelded | | | |
| Name | Left Side | Front | Right Side | Left Side | Front | Right Side | |
| 90° Elbow | + | + | 9 | | * | \bigcirc | |
| 45° Elbow | 0+ | X | -G+ | \$ | * | -()- | |
| Tee | + | + | $ \downarrow $ | | - | | |
| 45° Lateral | | X | 0 | 4 | • | -0 | |
| Cross | + | # | # | | + | | |
| Сар | | | | | <u></u> | | |
| Concentric Reducer | | 廿 | - ₩ | | * | | |
| Eccentric Reducer | | 4 | • | | - | ** | |
| Union | | <u> </u> | | | | | |
| Coupling | | | | ф | þ | • | |

Electronic Symbols

The following table shows basic examples of electronic drafting symbols.

