AutoCAD and Its Applications ADVANCED

Exercise 7-1

- 1. Start a new drawing.
- 2. Draw an arc anywhere on the screen. Make the radius approximately 5 units and the included angle 90° .
- 3. Rotate the UCS 90° about the X axis.
- 4. Draw another arc starting at one endpoint of the previous arc. Make the radius 20 units and the included angle 90°.
- 5. Start the **SWEEP** command, select the small arc as the profile, and select the large arc as the path.
- 6. Save the drawing as EX7-1A.
- 7. Start a new drawing.
- 8. Draw an ellipse with a major axis length of 15 units and a minor axis length of 6 units.
- 9. Rotate the UCS 90° about the Y axis.
- 10. Draw a 2D polyline starting at the center of the ellipse. Draw the polyline containing as many segments as you wish and in any shape. To create a smooth curve, edit the polyline, and turn it into a spline.
- 11. Start the **SWEEP** command, select the ellipse as the profile, and select the polyline as the path.
- 12. Save this drawing as EX7-1B.