

Exercise 9-3

1. Continue from Exercise 9-2 or start AutoCAD.
2. Start a new drawing from scratch or use a template of your choice. Save the drawing as EX9-3.
3. Access the **MTEXT** command and pick the first corner of the text boundary. Select the **Columns** option and then select the **No Columns** option. Pick the opposite corner to create a 4" (100 mm) wide by 2" (50 mm) high text boundary. Use relative coordinates or a similar point entry technique.
4. Use the Standard text style to type the following paragraph.

The text editor also makes it easy to enter the symbols for degrees ($^{\circ}$), plus/minus (\pm), diameter (\varnothing), greater than ($>$), and Omega (Ω).
5. Pick the **Close Text Editor** button to see the mtext object.
6. Resave and close the file.
7. Keep AutoCAD open for the next exercise, or exit AutoCAD if necessary.